

RIDMII

A Revolutionary AI Sex Doll Brand

Ridmii AI Doll User Manual

Ridmii.com



Contents

1. Powering On/Off	1
2. Wi-Fi Connection Setup	2
3. Accessing the AI Dialogue Interface & Adjusting Language Settings	3
4. Checking and Updating the AI System Version	4
5. Function Trigger Keywords	5
6. Important Safety & Usage Notes	6
7. Operation Guide Video	7
8. Q&A	8

Powering On/Off



1. Attach the doll's head to the body.



2. Find the screwdriver in the accessories, then use it to unscrew the two screws on the left and right of the back cover of the doll.

Powering On/Off



3. After removing the screws, take off the back cover.



4. Power on: Press and hold your finger for about 3 seconds until the screen lights up.
Power off: Press and hold your finger for about 3 seconds until the screen turns off.

Powering On/Off



5. After turning on the doll, go to the home page and swipe up from the bottom of the screen to access the apps page. Tap the triangle icon at the bottom of the screen to go back to the previous page. Tap the circular icon at the bottom of the screen to return to the home page. Tap the square icon at the bottom of the screen to zoom out of the app you're currently using. Swipe up to close the app.

Wi-Fi Connection Setup

Method one:



1. Swipe down from the top of the screen.
2. Click the Wi-Fi icon to turn on Wi-Fi.
3. Press and hold the Wi-Fi icon for 2 seconds to open the Wi-Fi management page. Find the Wi-Fi network you want to connect to, enter the password, and connect successfully.

Wi-Fi Connection Setup

Method two:



1. Swipe up from the bottom of the screen.



2. Go to the application software page, locate Settings, and click on it.

Wi-Fi Connection Setup



3. Find the Network & internet option and click it.



4. Turn on Wi-Fi by pressing and holding the button for 2 seconds. Then, find the Wi-Fi network you want to connect to and enter the password to connect successfully.

Accessing the AI Dialogue Interface & Adjusting Language Settings



1. Go to the application software page, locate the robot, and click on it.
2. When you enter the robot page, the system will automatically switch to dialogue mode.
3. Locate the function button in the upper right corner of the robot page. Click it, then scroll down to find the language option. Click on to select and switch to your preferred language. (Currently, only Chinese and English are supported, with more languages to be added in future updates.)

Checking and Updating the AI System Version



1. Enter the robot page.
2. Click the function icon in the upper right corner, scroll down on the function page, and find about version.
3. Click about version, then click check update version to check if the doll is the latest version. If it is not the latest version, you can click update to the latest version while connected to Wi-Fi.

Function Trigger Keywords

Functions	Keywords
Expressions	Make a face, smile, kiss. The doll will make corresponding expressions according to the instructions.
Change Language	Speak English.
Tell Story	Tell a story.
Change Doll's Name	Change name.
Arithmetic	One plus one.
Play a Song	Sing xxx(the song's name). Due to restrictions, only some songs can be played.
Stop Music	Stop music.
Stop speaking	Have a rest/ go to rest. Use the doll's name(Emma) can wake the doll up again.
Question& Answer Learning Function	Modify answer to my question.
Timed reminder function (Doesn't support reminder when the doll is power off.)	Reminder me go to work at 8:10 tomorrow/ every day.

Important Safety & Usage Notes

Avoid holding the head connector directly with your hands. When the doll is turned on, the head will rotate and the bottom of the head or the connector between the head and the body may cut your hands.



Oral sex is not recommended.

Operation Guide Video



Scan the QR code to watch the complete AI doll operation guide video.

Q&A

Q 1.What language model does the AI doll use?

A This doll's AI currently integrates DeepSeek, Doubao, and our self-developed database.

Q 2.How many languages does the AI doll support?

A Currently, the doll supports Chinese and English. We are continuously working on expanding and optimizing support for additional languages. English conversations are also being further trained and refined for better performance.

Q 3.Why is there sometimes a delay in responses during conversations?

A A delay of 1–3 seconds may occur when the AI processes open-ended questions that require deeper reasoning or real-time data synthesis.

Example 1: “What is the diameter of the Earth?” → real-time query, requires data processing.

Example 2: “What do you think about being with me?” → open-ended question, requires reasoning and analysis.

Q 4.Does the AI doll have memory capability?

A The current version supports contextual memory (remembering the ongoing conversation).

Q 5.What is the battery life?

A The doll is equipped with a 3400mAh battery. It takes about 2.5–3 hours to fully charge, and provides approximately 4.5–5 hours of active use on a full charge.

Special note: If you want to access the ChatGPT model, we can provide it for you, but it will cost extra.

RIDMII



 Facebook
(Ridmii Doll)



 Instagram
(@ridmiidoll)



 Twitter
(@RIDMIIDOLL)



 YouTube
(@RIDMIIDOLL)



 Reddit
(@RIDMIIDOLL)

 <https://ridmii.com>

 service@ridmii.com

 13th Floor, Area A, Chuangzhi Industrial Building, Dalang Street,
Longhua District, Shenzhen City, Guangdong, China